


Position Light set guideline



Kubiček
BALLOONS

Position Light set guideline

WARNING: this guideline is for brief info only, it cannot substitute the Flight manual supplement No. B.2102-NF.

Standard operation

Installation into the Basket

Install the bag into the basket before the flight. The bag is to be hanged at all four corners.

Approved store bag location:

- Inner side of the basket wall, within pilot's reach or
- Outer side of the basket wall, within pilot's reach on a side other than landing one - only if the envelope is fitted with rotation vents

During Flight

After take-off when clear of obstacles let the light down from the basket and switch it on by plugging the connectors.

Pull the light aboard the basket and store it in the bag before landing again.

Accumulator Charging

Always use the charger delivered with the light. The charging starts immediately after plugging the charger into the 230 V socket and its connector to the accumulator socket. The green and yellow LED will illuminate. Keep charging until the yellow LED turns off – the accumulator is fully charged.

If needed the charger can be kept connected for a long period of time, the charger will automatically re-charge it.

NOTE:

The charging time depends on the actual accumulator voltage and its age. E.g. a fully discharged 12 Ah accumulator may need 12-15 hours to be charged.

Position Light Malfunction

If the light is not working, check the connector and/or the fuse placed in a housing near the accumulator. If the fuse broken, replace it with the spare one.

If failure remains, follow the procedures prescribed in the Flight manual supplement, par. 3.14.

TAKE-OFF IS PROHIBITED with position light malfunctioning!